

String Chart for 36 STRING “SYLVAN” HEARTLAND HARP

1	-----	.025	-----	C-RED
2	-----	.025	-----	B
3	-----	.025	-----	A
4	-----	.025	-----	G
5	-----	.028	-----	F
6	-----	.028	-----	E
7	-----	.028	-----	D
8	-----	.032	-----	C-RED
9	-----	.032	-----	B
10	-----	.032	-----	A
11	-----	.032	-----	G
12	-----	.036	-----	F
13	-----	.036	-----	E
14	-----	.036	-----	D
15	-----	.040	-----	C-RED
16	-----	.040	-----	B
17	-----	.040	-----	A
18	-----	.040	-----	G
19	-----	.045	-----	F
20	-----	.045	-----	E
21	-----	.045	-----	D
22	-----	.050	-----	C-RED
23	-----	.050	-----	B
24	-----	.055	-----	A
25	-----	.045/.008	-----	G
26	-----	.045/.010	-----	F
27	-----	.050/.010	-----	E
28	-----	.050/.013	-----	D
29	-----	.050/.018	-----	C-RED
30	-----	.050/.020	-----	B
31	-----	.024/7/.018 SFB	-----	A
32	-----	.020/5/.008 SFB	-----	G
33	-----	.020/5/.010 SFB	-----	F
34	-----	.022/6/.010 SFB	-----	E
35	-----	.022/8/.010 SFB	-----	D
36	-----	.024/8/.015 SFB	-----	C-RED

IMPORTANT NOTE: Please do not put strings other than the ones designated above on your harp. To do so may cause severe stress on your soundboard, and lead to damaging your harp! To re-order strings, call Vermont Strings at 1-802-244-8564. Strings should be changed every 1-2 years.